

CFC FRAME PROTECTION FILM



WHAT IS INCLUDED AND WHERE DOES IT GO?

glossy or matt, no matter the set is the same



Examples:

This set covers almost every frame size.

645mm
615mm
604mm
584mm
572mm
561mm
553mm
541mm
529mm
524mm
510mm
498mm
491mm
480mm
461mm
448mm
437mm
430mm
418mm
405mm
386mm
374mm
344mm

The bicycle market has been booming since sustainability and environmental protection have come to the fore. Since there are thousands of different bicycles, here comes the universal solution.

The set offers different universal PaintProtectionFilm cuts, which can be put together depending on the bicycle frame. This means that every frame size and length can be covered.

The set includes the film cuts, 1 PaintProtectionFilm squeegee and 1 knife as well as mounting guide instructions.

EASY TO INSTALL

What is needed?

Squeegee, spray bottle filled with approx. 500ml of zero water (or distilled water), 1-2 ml ph-neutral detergent (non-re-greasing) or/and isopropyl cleaner 99. 9% 1-2 ml, paper towels.



1. Carefully remove the backing foil from the adhesive side.



4. Squeeze out slightly with the squeegee and so remove the water from the middle to the outside.



2. When releasing the carrier film, spray the adhesive side extensively with mounting agent (max. 1 drop of detergent per 500ml of water).



5. After approx. 30 to 60 minutes the paint protection film is firm. Full adhesive strength is reached after 24 hours at room temperature.



3. Also spray the surface to be bonded and cleaned beforehand. Now turn the sticker and place it in the desired position.

